
































Exploded diagram and spare parts list

CD231

Machine	Explode	Code	Description
CD231 Buffalo Heated Display Merchandiser	1		Control Panel
CD231 Buffalo Heated Display Merchandiser	2		Socket Connector
CD231 Buffalo Heated Display Merchandiser	3		Castor
CD231 Buffalo Heated Display Merchandiser	4-1		BS Plug
CD231 Buffalo Heated Display Merchandiser	4-2		Power Cord
CD231 Buffalo Heated Display Merchandiser	5-1	AF951	Temperature Thermostat
CD231 Buffalo Heated Display Merchandiser	5-2		
CD231 Buffalo Heated Display Merchandiser	5-3		
CD231 Buffalo Heated Display Merchandiser	6-1		Decoration Nut Gasket
CD231 Buffalo Heated Display Merchandiser	6-2		Nut Gasket
CD231 Buffalo Heated Display Merchandiser	6-3		Nut Decoration
CD231 Buffalo Heated Display Merchandiser	7	AD426	On/Off Switch
CD231 Buffalo Heated Display Merchandiser	8	AD427	Indicator Light
CD231 Buffalo Heated Display Merchandiser	9	AD428	Temperature Display
CD231 Buffalo Heated Display Merchandiser	10	AD429	Base Feet
CD231 Buffalo Heated Display Merchandiser	11		Door Metal Insert
CD231 Buffalo Heated Display Merchandiser	12		Door Glass
CD231 Buffalo Heated Display Merchandiser	13		Door Handle
CD231 Buffalo Heated Display Merchandiser	14		Left Pillar
CD231 Buffalo Heated Display Merchandiser	15		Right Panel
CD231 Buffalo Heated Display Merchandiser	16		Side Glass
CD231 Buffalo Heated Display Merchandiser	17		Left Panel
CD231 Buffalo Heated Display Merchandiser	18		Bottom Left Small Bracket
CD231 Buffalo Heated Display Merchandiser	19		Bottom Right Small Bracket
CD231 Buffalo Heated Display Merchandiser	20		Left Shelf Bracket
CD231 Buffalo Heated Display Merchandiser	21		Right Shelf Bracket
CD231 Buffalo Heated Display Merchandiser	22		Right Pillar
CD231 Buffalo Heated Display Merchandiser	23		Stainless Light Cover
CD231 Buffalo Heated Display Merchandiser	24		Curved Front Glass
CD231 Buffalo Heated Display Merchandiser	25		Sliding Glass Track
CD231 Buffalo Heated Display Merchandiser	26-3	AD737	Chrome Shelf 3
CD231 Buffalo Heated Display Merchandiser	26-2		Chrome Shelf 2
CD231 Buffalo Heated Display Merchandiser	26-1	AD729	Chrome Shelf 1
CD231 Buffalo Heated Display Merchandiser	27		Sliding Door Track
CD231 Buffalo Heated Display Merchandiser	28-1	AF497	U-Shaped Element from PO PO169485 onwards
CD231 Buffalo Heated Display Merchandiser	28-2	AF887	Bracket For Heater prior to PO169485
CD231 Buffalo Heated Display Merchandiser	29	AF886	Chassis Of Heater prior to PO169485
CD231 Buffalo Heated Display Merchandiser	30		Heater Brace

Exploded diagram and spare parts list CD231

spares@uropa-service.co.uk

CD231 Buffalo Heated Display Merchandiser	31		Radiator Bottom Plate
CD231 Buffalo Heated Display Merchandiser	32		Water Box
CD231 Buffalo Heated Display Merchandiser	33		Stainless Housing
CD231 Buffalo Heated Display Merchandiser	34		LED Light
CD231 Buffalo Heated Display Merchandiser	35		Socket
CD231 Buffalo Heated Display Merchandiser	36		Side Board Of Light Cover
CD231 Buffalo Heated Display Merchandiser	37	AF954	T1/33 Thermal Cut-out
CD231 Buffalo Heated Display Merchandiser	38	AF955	T1M/33 Thermal Cut-out

Exploded diagram and spare parts list CD231

 **Technical & Spares helpline - 0845 111 0538**

spares@uropa-service.co.uk