



Machine	Explode	Code	Description
CD679 - Adjustable Salamander Grill	1		Bottom plate assembly
CD679 - Adjustable Salamander Grill	2		Lower heat insulation plate
CD679 - Adjustable Salamander Grill	3	AD585	Indicator light(green)
CD679 - Adjustable Salamander Grill	3	AA031	Indicator light(red)
CD679 - Adjustable Salamander Grill	4	AD796	Energy regulator
CD679 - Adjustable Salamander Grill	5	N243	Knob
CD679 - Adjustable Salamander Grill	6		Oil tray
CD679 - Adjustable Salamander Grill	7	AD797	Grilling rack
CD679 - Adjustable Salamander Grill	8	AD798	Element
CD679 - Adjustable Salamander Grill	9	AD799	Handle
CD679 - Adjustable Salamander Grill	10		Top casing
CD679 - Adjustable Salamander Grill	11		Rear Casing
CD679 - Adjustable Salamander Grill	12		Horizontal rod assembly
CD679 - Adjustable Salamander Grill	13		Connection assembly
CD679 - Adjustable Salamander Grill	14		Vertical rod assembly
CD679 - Adjustable Salamander Grill	15		Small cable fixing plate
CD679 - Adjustable Salamander Grill	16		Counterweight assembly
CD679 - Adjustable Salamander Grill	17		Rear cover panel
CD679 - Adjustable Salamander Grill	18		Track for guide wheel
CD679 - Adjustable Salamander Grill	19		Upper fixing plate
CD679 - Adjustable Salamander Grill	20		Lower fixing plate
CD679 - Adjustable Salamander Grill	21		Lower short rod assembly
CD679 - Adjustable Salamander Grill	22		Power Cord
CD679 - Adjustable Salamander Grill	23	AC689	Feet